



- 5km study area buffer
- Bridleway
- Byway
- Footpath
- Restricted Byway
- Listed Buildings
- Scheduled Monuments
- Greenbelt
- Conservation Areas
- National Nature Reserves
- Special Protection Areas
- Ramsar
- Sites of Special Scientific Interest
- Special Areas of Conservation
- Flood Zone 2
- Flood Zone 3
- Southend Airport safeguarding zone

Dengie Marshes Wind Farm